

Solid-state Repeat Cycle Timer

H3CR-F

1/16 DIN Solid-state Repeat Cycle Timer

- Wide power supply ranges of 100 to 240 VAC 24 VAC/VDC, 12VDC
- Combinations of independent long or short ON/OFF time settings are possible
- Fourteen time ranges from 0.05 s to 30 h or 1.2 s to 300 h
- Repeat cycle models with either ON start or OFF start operating functions
- Easy sequence checks through instantaneous outputs for a zero set value at any time range
- 11-pin and 8-pin models are available

Ordering Information_





Timing units		0.05 s to 30 h		1.2 s to 300 h			
Terminal form		11-pin models	8-pin models	11-pin models	8-pin models		
Supply voltage	es	100 to 240 VAC, 24 VAC/DC, 12 VDC					
Operating mode		Repeat cycle					
Part number	Repeat cycle OFF start	H3CR-F	H3CR-F8	H3CR-F-300	H3CR-F8-300		
	Repeat cycle ON start	H3CR-FN	H3CR-F8N	H3CR-FN-300	H3CR-F8N-300		

Note: Specify both the model number and supply voltage when ordering. Example: H3CR-F <u>24 VAC/DC</u> Supply voltage

■ MODEL NUMBER LEGEND



Classification
 F: Repeat cycle timers
 Configuration
 None: 11-pin socket
 8: 8-pin socket

3. Repeat cycle mode
None: OFF start
N: ON start
4. Specified Type
300: Long time range (1.2 s to 300 h) type

ACCESSORIES (ORDER SEPARATELY)

Description		Part number
Panel mounting	Fits behind panel, ideal for side by side installation. Use P3G-08 socket.	Y92F-30
adapters	Installs through panel front; timer face fits bezel, rear of timer clips to adapter. Use P3G-08 socket. Fits 65-66 mm (2.56-2.59 in) x 52-53 mm (2.04-2.09 in) panel cutout. Charcoal gray face plate measures 88 H x 58 W mm (3.46 x 2.28 in)	Y92F-73
	Installs through panel front; timer face fits bezel, rear of timer clips to adapter. Use P3G-08 socket. Fits 55 x 45 mm (2.17 x 1.77 in) panel cutout. Charcoal gray face plate measures 58 H x 50 W mm (2.28 x 1.97 in)	Y92F-74
Mounting track	DIN rail, 50 cm (1.64 ft) length, 7.3 mm (0.29 in) depth	PFP-50N
	DIN rail, 1 m (3.28 ft) length, 7.3 mm (0.29 in) depth	PFP-100N
	DIN rail, 1 m (3.28 ft) length, 16 mm (0.63 in) depth	PFP-100N2
	End Plate	PFP-M
	Spacer	PFP-S
Protective Cover	Hard plastic cover protects against dust, dirt and water; not for use with panel covers.	Y92A-48B
Sockets	Bottom surface or track mounting, top screw terminals. Use with 8-pin terminal form timer.	P2CF-08
	Bottom surface or track mounting, top screw terminals. Use with 11-pin terminal form timer.	P2CF-11
	Back mounting, for use with Y92F-30 mounting adapter, bottom screw terminals. Use with 8-pin terminal form timer.	P3G-08
	Back mounting, for use with Y92F-30 mounting adapter, bottom screw terminals. Use with 11-pin terminal form timer.	P3GA-11

RANGE SELECTION

OFF indicator (green) Lit when the output is OFF. ON indicator (orange) Lit when the output is ON.

Scale range display windows



OFF-time unit display window

OFF-time unit selector (select one from sec. 10 s, min., and hrs, or from 10 s, 10 min, hrs, and 10 h)

ON-time setting knob (with orange pointer) For ON-time setting

OFF-time setting knob (with green pointer) For OFF-time setting

ON-time unit display window

ON-time unit selector (select one from sec. 10 s, min., and hrs, or from 10 s, 10 min, hrs, and 10 h)

0.05 s to 30 h models

Time	Time units						
range	s (sec)	x 10 s (10 s)	min	h (hrs)			
1.2	0.05 to 1.2	1.2 to 12	0.12 to 1.2				
3	0.3 to 3	3 to 30	0.3 to 3				
12	1.2 to 12	12 to 120	1.2 to 12				
30	3 to 30	30 to 300	3 to 30				

Time range selector (select one from 1.2, 3, 12, and 30) For both ON-time and OFF-time.

Note: Instantaneous output is available at any time range. To obtain instantaneous output, set to below 0.

1.2 s to 300 h models

Time range	Time units						
	x 10 s (10 s)	x 10 min (10 min)	h (hrs)	x 10 h (10 h)			
1.2	1.2 to 12	1.2 to 12	0.12 to 1.2	1.2 to 12			
3	3 to 30	3 to 30	0.3 to 3	3 to 30			
12	12 to 120	12 to 120	1.2 to 12	12 to 120			
30	30 to 300	30 to 300	3 to 30	30 to 300			

Note: Instantaneous output is available at any time range. To obtain instantaneous output, set to below 0.

Specifications_____

Part number		H3CR-F/-F-300	H3CR-F8/-F8-300	H3CR-FN/-FN-300	H3CR-F8N/-F8N-300				
Operating mode		OFF start		ON start					
Supply	AC	100 to 240 VAC (50/60 Hz)							
voltage	AC/DC	24 VAC/DC (50/60 Hz)	24 VAC/DC (50/60 Hz)						
(see note)	DC	12 VDC							
Operating volt	age range	85% to 110% of rated s	supply voltage, 90% to 1	10% with 12-VDC mode	ls				
Power	AC	100 to 240 VAC: 10 VA (100 VAC applied)							
consumption	AC/DC	24 VAC/DC: 2 VA (24 VAC applied)/1 W (24 VDC applied)							
	DC	12 VDC: 1 W							
Start, Reset, C	Gate inputs	ON-impedance: 1 kΩ ON residual voltage: 1 OFF impedance: 500 l	max. V max κΩ min.						
Control	Туре	DPDT relay							
outputs	Max. load	5 A at 250 VAC, p.f. = 7	1						
	Min. load	10mA at 5 VDC							
Repeat accuracy		$\pm 0.3\%$ full scale max. ($\pm 0.3\%$ full scale max. ± 10 ms in ranges of 1.2 and 3 s)							
Setting error		±5% full scale max ±0.05 s max.							
Resetting syst	em	Time-limit operation/time-limit reset or self-reset							
Resetting time)	Minimum power-opening time: 0.1 sec							
Indicators		Output ON indicator (orange LED), output OFF indicator (green LED)							
Materials		Plastic case (light gray Munsell 5Y7/1)							
Mounting		Panel, DIN track, or surface depending on socket selected							
Connections		11-pin round socket	8-pin round socket	11-pin round socket	8-pin round socket				
Weight		Approx. 100 g (4.23 oz.)							
Approvals		UL/CSA/(EMC)/(LV)							
Ambient	Operating	-10° to 55°C (14° to 13	31°F) with no icing						
temperature	Storage	-25° to 65°C (-13° to 149°F) with no icing							
Humidity		35% to 85%							
Vibration	Mechanical durability	10 to 55 Hz with 0.75-mm single amplitude each in three directions							
	Malfunction durability	10 to 55 Hz with 0.5-mm single amplitude each in three directions							
Shock	Mechanical durability	980 m/s ² (100G) each in three directions							
	Malfunction durability	98 m/s ² (10G) each in three directions							
Variation due to voltage change		$\pm 0.5\%$ full scale max. ($\pm 0.5\%$ full scale max. ± 10 ms in ranges of 1.2 and 3 s)							
Variation due to temperature change		±2% full scale max. (±2% full scale max. ±10 ms in ranges of 1.2 and 3 s)							
Service life	Mechanical	20 million operations m	iin. (under no load at 1,8	00 operations/h)					
	Electrical	100,000 operations min. (5 A at 250 VAC, resistive load at 1,800 operations/h)							
Insulation resistance		100 MΩ min. (at 500 VDC)							

Note: A power supply with a ripple of 20% max. (single-phase power supply with full-wave rectification) can be used with each DC model.

Engineering Data.



Note: A maximum current of 0.15 A can be switched at 125 VDC (cosf = 1) and a maximum current of 0.1 A can be switched if L/R is 7 ms. In both cases, a life of 100,000 operations can be expected. The minimum applicable load is 10 mA at 5 VDC (failure level: P).

Operation_

BLOCK DIAGRAMS



Timing Charts.

H3CR-F8 H3CR-F8N H3CR-F8-300 H3CR-F8N-300



H3CR-F H3CR-FN H3CR-F-300 H3CR-FN-300



Note: Leave terminals 5, 6, and 7 open. Do not use them as relay terminals.





Dimensions.

TIMERS

Unit: mm (inch)



TRACK MOUNTING

11-pin models P2CF-11



8-pin models P2CF-08



*These dimensions vary with the kind of DIN track (reference value).

PANEL MOUNTING

11-pin models



8-pin models



PANEL MOUNTING ADAPTERS

Unit: mm (inch)

Y92F-30

Adapter installs behind the panel. It is ideal for side by side installation. Use P3G-11 or P3G-08 sockets.



Y92F-73









Note: The mounting panel thickness should be 1 to 3.2 mm.

Y92F-74





Note: The mounting panel thickness should be 1 to 3.2 mm.

4.5

SOCKETS

Track mounting/front connecting socket

4

4 2

Eight M3.5 x 7.5 sems ----

P2CF-08









- 7.8

3

Terminal Arrangement/ Internal Connections (Top View)



8000

@@@@

Surface Mounting Holes

Two, 4.5 dia. or two, M4





Back mounting socket

P3G-08







. 31.2 max.

Terminal Arrangement/ Internal Connections (Bottom View)



P3GA-11









■ PROTECTIVE COVER

Y92A-48B



The hard plastic protective cover prevents accidental resetting. It also shields the front panel from dirt and water. The cover is intended for use in areas where unusual service conditions do not exist. The Y92A-48B cover cannot be used with the Y92P Panel Covers below.

MOUNTING TRACK AND ACCESSORIES

PFP-100N/PFP-50N



Note: The values shown in parentheses are the the PFP-50N.

PFP-M End Plate





PFP-S Spacer



Connections

Part number	Input terminal number		Power supply terminal numbers		Output terminal numbers		
	COM	Reset	AC (common), DC-	AC (hot), DC+	COM	NC	NO
H3CR-F8 H3CR-F8N H3CR-F8-300 H3CR-F8N-300	-	_	2	7	1 8	4 5	3 6
H3CR-F H3CR-FN H3CR-F-300 H3CR-FN-300	—	_	2	10	1 11	4 8	3 9

Installation.



The neutral or common of the power supply is connected to terminal 2. Terminal 7 of H3CR-F 8-pin terminals and terminal 10 of H3CR-F 11-pin terminals should be connected to the "hot" or positive of the power supply.



Design your control circuit using the relay contacts to switch the load. Never switch a load with the contact that is being used as an input signal. The timer's circuitry may be damaged.

SELECTING TIME RANGES

A time range (0 to 1.2, 0 to 3, 0 to 12, or 0 to 30) is selected for ONand OFF-time using the time range selector at the lower left corner of the front panel, and the selected time range appears within the plastic frame of the time setting knob (= scale range display windows).

For ON-time, the desired time unit (sec, 10 s, min, and hrs, or 10 s, 10 min, hrs, and 10 h) is indicated in the ON-time unit display window at the lower right corner of the front panel and can be changed by turning the ON-time unit selector located below the ON-time unit display window.

For OFF-time, the desired time unit (sec, 10 s, min, and hrs, or 10 s, 10 min, hrs, and 10 h) is indicated in the OFF-time unit display window at the upper right corner of the front panel and can be changed by turning the OFF-time unit selector located below the OFF-time unit display window.

TRACK MOUNTING



Mounting

The P2CF- \Box socket has two hooks that secure the time to the socket. Be sure to allow at least 20 mm (0.79 in) clearance above and below the socket to gain access to release the hooks for servicing and maintenance. Then clip rear of the socket to the track. Push the bottom onto the track until the latch hooks securely.



Removal

Pull the latch on the socket with a flat-blade screwdriver and remove the timer and socket as one unit.

Using Y92F-73 and Y92F-74 Adapters

Install the H3CR-H timer, face first, into the back side of the Y92F-73 or Y92F-74 adapter so the bezel fits snuggly. Be sure the retaining clips at the back of the adapter fit into the slots on either side of the timer. Compress the top and bottom tabs of the adapter then push the adapter through the front side of the panel cutout. Be sure the tabs extend after the installation for a secure fit.

To remove the timer from the adapter, unclip the two retaining clips at the back of the adapter. To remove the adapter and timer from the panel as a unit, compress the tabs behind the panel and push the unit out the front of the panel.

Precautions.

To avoid malfunction or damage, do not change the time unit or time range while the timer is in operation. Be sure to turn off the power supply to the timer before changing any of the selections.





NOTE: DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters to inches divide by 25.4.

Omron Europe B.V. EMA-ISD, tel:+31 23 5681390, fax:+31 23 5681397, http://www.eu.omron.com/ema