

Sensing

E2K-C

ĀΣ

200 mA

Output

200 mA,

NPN or PNP

Cylindrical Sensor Offers Adjustable Detecting Distance

- Permits non-contact detection of metallic and non-metallic objects such as glass, wood, water, oil and plastic
- Allows indirect detection of materials inside non-metallic containers
- Adjustable detecting distance from 3 to 25 mm
- Built-in amplifier accepts wide range of supply voltages and switches up to 200 mA
- Mounting bracket included

### **Ordering Information**

### ■ SENSORS


Туре			Unshielded		
Nominal detecting distance			3 to 25 mm (0.12 to 0.98 in), adjustable		
Output type			NO	NC	
Part	AC switching type (SCR)		E2K-C25MY1	E2K-C25MY2	
number	DC switching type	NPN	E2K-C25ME1	E2K-C25ME2	
		PNP	E2K-C25MF1	E2K-C25MF2	


### ■ REPLACEMENT PARTS

Description	Part number	
Mounting bracket for E2K-C (supplied with sensor)	Y92E-A34	

### ■ TYPICAL APPLICATIONS

### Detecting fill level in non-metallic containers





Detecting and maintaining level of liquid in storage tanks



Supply voltage 90 to 250 VAC, 50/60 Hz

10 to 40 VDC


## Specifications \_\_\_\_\_


Part numb	er		E2K-C25M	E2K-C25MY			
Sensor type			Capacitive				
Body Size		Size	34 mm (1.34 in) diameter				
		Туре	Unshielded				
Supply voltage			10 to 40 VDC, 10% max. permissible ripple peak to peak	90 to 250 VAC, 50/60 Hz			
Current consumption		on	10 mA max. at 12 VDC 15 mA max. at 24 VDC	1 mA max. at 100 VAC 2 mA max. at 200 VAC			
Detectable object type		type	Metallic and non-metallic objects				
Sensitivity			Adjustable				
Effective maximum detecting distance (with standard target)			3 to 25 mm (0.12 to 0.98 in)				
Standard target size (grounded mild steel, L x W x H)		ze el, L x W x H)	50 x 50 x 1 mm (2.0 x 2.0 x 0.04 in)				
Differentia	l travel	· · ·	15% max. of detecting distance				
Control output	AC solid-	Туре	_	SCR-NO (E2K-C25MY1) SCR-NC (E2K-C25MY2)			
	state	Max. load	-	200 mA			
		Min. load	_	5 mA			
		Max. off-state	_	See "Leakage Current Characteristics"			
		leakage current		graph in Engineering Data			
		Max. on-state	—	2V max.			
		voltage drop					
	DC solid- state	Туре	NPN-NO open collector with pull-up NPN-NC open collector with pull-up PNP-NO open collector with pull-down PNP-NC open collector with pull-down	_			
		Max. load	200 mA				
		Max. on-state	See "Residual Load Voltage" graph in	_			
		voltage drop	Engineering Data				
Response frequency		су	70 Hz	10Hz			
Circuit protection Output short- circuit DC power supply reverse polarity Weld field immunity			Not provided				
			Provided	Not provided			
		Weld field immunity	Not provided				
		RFI immunity	Not provided				
Indicators			Target Present (red LED)	Output Operation (red LED)			
Materials		Housing	Plastic				
		Sensing face	Plastic				
		Cable sheath	Plastic				
Mounting			Bracket Y92E-A34 included				
Connections Prewired		Prewired	Three-conductor cable, 2 m (6.56 ft) length Two-conductor cable, 2 m (6.56 ft) length				
Weight with cable			Approx. 200 g (7.0 oz.)				
		UL	1				
		NEMA	1, 4, 12, 13				
		IEC 144	IP67				
Approvals		UL		Listed, File Number E76675			
		CSA		Certified, File Number LR45951			
Ambient operating temperature		temperature	–25° to 70°C (–13° to 158°F)				
Vibration			10 to 55 Hz, 1.5 mm (0.06 in) double amplitude				
Vibration							

### ■ OUTPUT CIRCUIT DIAGRAMS AND TIMING CHARTS

### **AC Switching Types**

E2K-C25MY






Note: IEC colors are shown in parentheses.

### **DC Switching Types**


### E2K-C25ME

The dotted line shows a transistor circuit load.



Note: IEC colors are shown in parentheses.

**E2K-C25MF** The dotted line shows a transistor circuit load.




		E2K-C25ME1 NO	E2K-C25ME2 NC			E2K-C25MF1 NO
Target	Present			Target	Present	
	Absent -				Absent	
Load (between red and white)	Operates Releases	<b></b>		Load (between white and black)	Operates Releases ——	
Logic (between white and black)	Н		nd hr	Logic (between	н	
	L –			red and white)	L —	
Operation indicator	ON OFF —			Operation indicator	ON OFF	


# E2K-C25MF2 NC

### **Engineering Data**

### Operating Range E2K-C25MY1



### Detecting Distance vs. Size and Material of Target




### **Residual Load Voltage Characteristics**

AC switching types E2K-C25MY

value of


the resistor.



Note: When the current rating of the load is less than 10 mA, false operation may


occur. This is normal, and the problem can be cured by installing a bleeder resistor in parallel with the load. Use the formulas given here to calculate the power rating and

DC switching types E2K-C25M□□



V<sub>s</sub> : Supply voltage (V)

### Leakage Current Characteristics




### **Dimensions**

Unit: mm (inch)

### SENSORS






Note: Cable may be extended to 200 m (656 ft).

### MOUNTING BRACKET


### Y92E-A34 (supplied with sensor)




### Mounting

### ■ EFFECTS OF SURROUNDING METALS

When mounting the sensor, be sure to provide the minimum distance shown in the diagram. This prevents the sensor from being affected by metallic objects other than the target. Also, when using the supplied mounting bracket, be sure to allow a distance of 20 mm or more between the detecting face and the mounting bracket.






#### Surrounding conductive obiect


### MUTUAL INTERFERENCE

To prevent mutual interference, be sure to space the two sensors at a distance greater than that shown in the diagrams.

### **Opposed mounting**




#### Parallel mounting



### SENSITIVITY ADJUSTMENT

#### NO type (E2K-C25M□1)

Remove protective rubber plug to gain access to sensitivity adjustment screw. Use the screwdriver provided with each sensor to turn the sensitivity adjustment screw.



 Remove any targets from in front of the sensor. Turn the sensitivity adjustment screw CLOCKWISE until the sensor turns ON and the indicator illuminates.

Sensitivity adjustment



Stop when the sensor turns ON

2) Place a target in front of the sensor. Turn the sensitivity adjustment screw COUNTERCLOCK-

WISE until the

sensor turns OFF and the indicator goes out. Note the number of revolutions between OFF and ON positions. Sensitivity adjustment



Stop when the sensor turns OFF


3) If the number of revolutions is greater than one and a half,

the sensor will provide stable output. If the number of revolutions is less than one and a half, increase or decrease the distance


between the target and the sensing face as necessary to allow at least one and a half

2

revolutions between the ON and OFF positions. (1) ON point



 Now turn the sensitivity adjustment screw CLOCKWISE to the midpoint between the ON and OFF points.



5) If the distance between the target and the sensor is not constant, perform

the first adjustment

operation (#1) when the target is at the closest position to the sensor. Then perform the second

- adjustment operation (#2) when the
- target is at the farthest position from the sensor.

### NC type (E2K-C25MQ2)

The sensitivity adjustment procedure for NC type proximity sensors is the same as for NO type sensors, with the exception that ON and OFF operations of the proximity sensor and ON and OFF points in the adjustment procedure are exactly reversed.

### USING METAL CONDUIT

If a high voltage of power line runs near the proximity sensor cable, be sure to wire the sensor cable through a metal conduit to protect the sensor from malfunctioning or damage.


### SURGE PROTECTION

The proximity sensor is provided with a surge suppressor circuit. However, if any large surge generating source (i.e., motor, welding machine, etc.) exists in the vicinity of the proximity sensor, insert a surge suppressor (such as a varistor) into the surge generating source.

### **Application Examples**


For two-unit control to directly detect a water level, use type E2K-C25ME1 and E2K-C25ME2 proximity sensors together as a pair, connected as shown in the examples below.

### For water supply control by directly detecting the water




#### **Timing Chart**

Connect water supply valve "A" to the NO contact of sensor controller S3S-B10-US.




### For water drainage control by directly detecting the water level



#### **Timing Chart**

Connect the drain valve "B" to the NO contact of sensor controller S3S-B10-US.



NOTE: ALL DIMENSIONS ARE IN MILLIMETERS. To convert millimeters into inches divide by 25.4

# OMRON

Omron Europe B.V. EMA-ISD, tel:+31 23 5681390, fax:+31 23 5681397, http://www.eu.omron.com/ema

Cat. No. CEDSAX2